

Fontana Pahua Brushed Nickel Two Handles Bathtub Faucet with Hand Shower

Product Code: FS7914BN



BEFORE YOU BEGIN

Before you begin, please read the installation instructions below. Observe all local building and safety codes.

Unpack and inspect the items for any shipping damages. If you find damages, do not install.

Please note all products must be installed by a professional and certified plumber otherwise warranty might be voided.

POSSIBLE TOOLS REQUIRED*



Plumbers Tape



Tape Measure



Level



Adjustable Wrench



Hex Wrench



Thread Sealant



Drill



Pencil or Marker



Screwdriver

*not included

Fontana Pahua Brushed Nickel Two Handles Bathtub Faucet with Hand Shower

Product Code: FS7914BN

Installation Instructions:

1. If your faucet comes with the brass T attached to the faucet body, unthread and remove the T and associated hardware.
2. Thread the silver mounting washer and rubber sealing gasket on the faucet body.
3. Apply a bead of silicone sealant to the underside of the spout, or faucet base, and thread through the center mounting hole.
4. Thread the mounting hardware and brass T onto the spout pipe and hand-tighten to secure.
5. Check to make sure the faucet is properly aligned and adjust as needed. When the faucet is in the proper position, finish tightening mounting hardware with your adjustable wrench.
Tip: Make sure that the T outlets are aligned at an angle to allow maximum clearance for water connections.
6. Wipe away any excess sealant around the faucet base using your damp cloth.
7. Assemble the handles by screwing the lock nuts down to the end of the handle bodies. If handles are assembled, move on to step 8.
8. Insert the handle bodies up through the mounting holes. Thread the plastic slip washers and rubber sealing gaskets onto the handle bodies to secure.
9. Hand tighten to attach the hot and cold flexible water feed tubes to the handle bodies and brass T. Give a 1/4 turn with pliers or wrench, but don't over tighten. (Hot water is always on the left and cold water is always on the right.) Curve tubes as necessary to ensure there are no kinks or knots.